OMNIPRESENT DJ & LIGHTING

DUAL SPEAKER SETUP

Self-Serve Sound System | Customer setup guide

QUICK START • TWO SPEAKERS

To play the same music through both speakers, connect them to one music device using a wired splitter.

IMPORTANT: These Pyle speakers do not pair to each other over Bluetooth. A stereo headphone Y-splitter with two AUX cables is a separate wired workaround, not built-in speaker linking.

1 Position both speakers

Place one stable, compatible tripod on each side of the listening area. Secure the stands and carefully mount each speaker.

2 Power on both units

Charge both speakers or connect each supplied power adapter. Turn both rear POWER switches ON.

3 Connect the audio cables

Plug a stereo 3.5 mm headphone Y-splitter into your music device. Run one 3.5 mm AUX cable to each speaker's AUX input. Select AUX mode on both.

TWO-SPEAKER KIT



Needed for shared music:

- 1 phone/laptop
- 1 stereo Y-splitter
- 2 AUX cables
- Device adapter, if needed

Note: The splitter, AUX cables and phone adapter are not standard accessories in Pyle's speaker box. Confirm what is included in your rental kit.

HOW THE CONNECTION WORKS

PHONE / LAPTOP → Y-SPLITTER → BOTH AUX INPUTS

Always test the exact splitter and cables before the event.

OMNIPRESENT DJ & LIGHTING

DUAL SPEAKER TIPS

Self-Serve Sound System | Customer setup guide

PLAY MUSIC, USE MICROPHONES & PACK UP

Both speakers use their own controls; set and check each one separately.

Play music on both

- Open your music app and press Play.
- Make sure both speakers are on AUX mode.
- Start with low volume, then adjust the phone and each speaker gradually.
- Walk the room and confirm the music plays through both speakers.

Wireless microphones

- Each speaker has its own included microphone.
- Insert 2 AA batteries into each microphone.
- Turn one microphone on and adjust MIC VOL on its matching speaker.
- A microphone on one speaker does not automatically come out of both. Test both mics before use.

Not hearing music from both?

Check that each speaker is ON, both are in AUX mode, both AUX plugs are fully inserted, and neither speaker has its volume turned down. If available, try each cable separately.

When the event ends

- [ ] Stop playback
- [ ] Turn OFF both speakers and microphones
- [ ] Disconnect and coil cables
- [ ] Pack both speakers, stands and accessories

Important safety tips

- Keep power and audio cables out of walkways.
- Keep speakers away from liquids and moisture.
- Use secure stands on level ground.
- For longer events, use supplied power adapters.

Battery runtime depends on use.

Product reference: https://pyleusa.com/products/psbt125a | The dual AUX layout is a conventional analog splitter setup.