OMNIPRESENT DJ & LIGHTING

SINGLE SPEAKER SETUP

Self-Serve Sound System | Customer setup guide

QUICK START • ONE SPEAKER

Follow these four steps to play music and use your wireless microphone.

1 Set up the stand

Open the tripod legs on a firm, flat surface. Tighten the stand adjustments, then carefully place the speaker on the compatible stand.

2 Turn on the speaker

Charge the speaker or connect its supplied power adapter. Move the rear POWER switch to ON.

3 Connect Bluetooth music

Press MODE until Bluetooth mode is selected. On your phone or tablet, open Bluetooth settings and select Pyle PSBT125A. Play music and raise VOLUME gradually.

4 Turn on the wireless mic

Insert 2 AA batteries in the microphone. Turn it on and adjust the speaker's MIC VOL knob. Use ECHO only if you want that effect.

YOUR SPEAKER



Pyle Bluetooth PA

12-inch • built-in battery

CHECK YOUR RENTAL KIT

Speaker • Mic • Remote • Power adapter • Compatible tripod (if supplied)

Before guests arrive: Test your music and microphone at the intended location.

QUICK FACT

Bluetooth is for music from your device. The supplied wireless microphone uses its own radio connection to the speaker.

Details and safety checks continue on page 2.

SINGLE SPEAKER TIPS

Self-Serve Sound System | Customer setup guide

SOUND CONTROLS & TROUBLESHOOTING

Use these quick checks if you need wired audio or do not hear music or microphone sound.

Useful controls

- MODE - switches the input mode (Bluetooth, AUX, etc.).
- VOLUME - adjusts music/speaker level.
- MIC VOL - adjusts microphone level.
- ECHO - adds microphone echo.
- BASS / TREBLE - adjust low and high tones.

If something is wrong

- No music? Check POWER, selected mode, phone Bluetooth connection, and volume.
- No microphone? Check its 2 AA batteries, power switch, and MIC VOL.
- Loud squeal? Move the microphone away from the speaker and lower MIC VOL.
- Bluetooth cutting out? Move your device closer, or use AUX audio.

Optional wired music (AUX)

Connect a compatible 3.5 mm audio cable from your device to the speaker's AUX input. Press MODE to select AUX. Some phones require a headphone adapter.

End-of-event checklist

- [ ] Stop music and switch speaker OFF
- [ ] Switch microphone OFF
- [ ] Disconnect and pack accessories
- [ ] Return the speaker and tripod, if supplied

Keep it safe

- Keep away from rain, water, and spilled drinks.
- Route cables away from walkways.
- Use a stable, compatible tripod.
- Battery runtime varies; use the supplied power adapter for longer events.

Product reference: https://pyleusa.com/products/psbt125a